cliona by KIIRO°

setup guide

Cliona by KIIROO is to be used with the authorized FeelConnect App only.


Downloading any third-party applications to control or interact with the Cliona that is not mentioned above is done entirely at your own risk. In the event that a third-party application is downloaded and it damages either the device software or hardware or leads to personal injury, neither KIIROO, FeelConnect or any of their partners will be held liable. In the event that third party applications are downloaded, the device warranty will be void.

TABLE OF CONTENTS

SETTING UP YOUR DEVICE Using your device	4	HANDLING AND LUBRICATION Cleaning	9
MODES Bluetooth Mode	6	DISCLAIMER AND WARNINGS	10
Manual Mode	8	DISPOSAL SPECIFICATIONS	11
CHARGING AND LED INDICATOR To charge your device LED Indicator		AFTERCARE AND HELP Specifications Help Opening hours	12

SETTING UP YOUR DEVICE

1. Using the Pin USB charger provided, charge Cliona until the light turns green; about 2 hours. We recommend charging Cliona fully prior to the first use. While charging, the LED indicator flashes red.




The charging port can be found at the bottom of Cliona.

2. Go to www.kiiroo.com to create your user account. https://www.KIIROO.com/my-account/
https://www.KIIROO.com/account/register

- 3. Once you have created an account, please go to: https://www.KIIROO.com/pages/register-your-device to register your device and activate your one (1) year warranty.
- 4. Download the FeelConnect App to pair your device with your mobile phone. Detailed instructions on connecting to the FeelConnect App can be found here: https://www.KIIROO.com/pages/support

USING YOUR DEVICE

- 1. To power on, press and hold the power button for 4 seconds.
- 2. A rapidly flashing blue light will show and the device is now in Bluetooth Mode (go to page 7).



- 3. Double click the power button to go into Manual Mode. The light will turn pink. When the light flashes, you can use the arrows to cycle through the modes. Use the + and to make the speed of each pattern stronger or weaker. Click the power button once to lock the touch-sensitive buttons. (go to page 7).
- 4. To go back to Bluetooth Mode, double click the power button again. A rapidly flashing blue light will return.
- 5. To turn off the device, hold the power button for 4 seconds until the light goes off.

MODES

Bluetooth Mode: Indicated by blue light.

Once Cliona is on, it is in Bluetooth Mode. This is indicated by the blinking blue light. Download our app to sync your device to interactive content, or connect to a partner(s) device.

Learn how at: www.KIIROO.com/connect





To change modes, double-click the multifunctional power button. Cliona is now in Manual Mode. This is indicated by the blinking white light.

Manual Mode: Indicated by pink light

Cliona responds intuitively to touch. The vibration patterns and intensities can be controlled easily by sliding your finger over the buttons you want to touch.



MANUAL MODE



Patterns

Cliona has 4 different vibration patterns. Choose your favorite pattern by tapping the Right or Left touch sensitive arrow.



Vibration Intensity

Once you have selected your pattern, you can control the vibration intensity. Tap + for a stronger vibration, or - for a softer one.



Deactivate/Activate Touch


Once you have selected your desired Vibration Pattern and Intensity, you can: Deactivate touch-sensitivity by clicking the multifunctional power button once. Reactivate it by pressing power button again.

CHARGING AND LED INDICATOR

1. Insert the Pin USB Charger cable into Cliona's charging point. The Pin point is located at the very bottom of Cliona.

- 2. Insert the other end into a USB port. This can be a computer or wall adapter. Charging by computer may exceed 2 hours.
- 3. Wait for the LED light to blink slowly, indicating that Cliona is charging.

Charge 1 hour for 1.5 hours of use.



Please note: wall adapter is NOT included in the box.

- 4. The LED light will glow solid Green when Cliona is fully charged.
- 5. When the battery is low, the LED indicator will prompt you to charge by flashing red*.

*If the LED indicator flashes red quickly the battery is critically low. You will have 5 minutes before Cliona disconnects from Bluetooth and turns off.

6. The LED indicator will blink continually if an update is available or if something has gone wrong.

BLUE Bluetooth mode
WHITE /PINK Manual Mode
GREEN Fully charged
RED Battery low

BLINKING RED • Battery critically low, 5 minutes until disconnect

BLINKING BLUE/RED • Cliona is updating

HANDLING AND LUBRICATION

Lubrication

Hold Cliona at the base of the device and apply a generous amount of water-based lubricant to the head.

Recommended:

Always use water-based lubricant.
 Using lubricant will prolong the lifespan of Cliona and give you the most comfortable experience.

Do not use:

- 1. Silicone lubricant as it will deteriorate the silicone of Cliona.
- 2. Massage oils or hand cream as lubricants.
- 3. Cliona anally.

Please note: Cliona is not a hands-free device. Cliona is intended for vaginal use only.

Cleaning

Always clean Cliona thoroughly after each use. Use warm water along with antibacterial soap, dish soap or a specialized toy cleaner.

Avoid cleaners that contain alcohol, petrol, acetone or harsh soaps as this will damage the silicone of the Cliona.

Please note: Hygiene silicone is an easy material to clean. It will last for years when taken care of properly.

DISCLAIMER & WARNINGS

We, KIIROO, make no medical claims with our devices.

Our devices are not to be used by or on minors (anyone under 18), or anyone who is unable or unwilling to express consent.

Follow all directions as set forth by the manual, and do not attempt to make any technical adjustments to your KIIROO device at home.

KIIROO will not be held responsible for any undesirable results of misuse.

Do NOT use your Cliona:

- If there are exposed electronic elements
- If it is excessively hot to touch
- Anally
- On inflamed or irritated areas

Avoid leaving your Cliona in direct sunlight and NEVER expose it to extreme heat.

Never use cleansers containing alcohol, petrol or acetone.

Do not use heating appliances to dry the device.

Avoid using harsh soaps as they can damage the silicone material.

Always store the device out of reach of children.

The Bluetooth module is located in the base. For personal safety and optimal reception, do not insert Cliona more than 5 cm in.

DISPOSAL SPECIFICATIONS

While Cliona is made of eco-conscious materials, you should not dispose of Cliona in your waste bin. Like any electronic device with a rechargeable battery, there are disposal regulations; these vary by city and local municipality. Be aware of how electronics are disposed of where you live.

Also consider that in your locality, Cliona may be considered bio-waste because of its intimate nature. KIIROO recommends asking your local council center about disposal of bio-waste and electronic products.

AFTERCARE AND HELP

Product Specifications:

Materials: ABS, silicone

Finish: Matte chrome for ABS, matt finish for silicone

Size: Approx. 11.5 x 5 x 4 mm
Weight: Approx. 75g without box
Battery: Lithium-ion 540 MAH 3.7V

Charging: 2 hours User time: 1 hour

What you get in the box:

Cliona by KIIROO USB Charging cable Authenticity & Warranty Card Quick Setup Manual

Help

If you have any problems with setup and installation, or issues with using your device, do not hesitate to contact our Customer Support Team. Our team is there for your support, to explain and solve problems in detail, and to make sure your online experience runs as smoothly as possible.

We try to answer all questions within 48 hours of receiving them.

For frequently asked questions visit:

www.KIIROO.com/faq www.KIIROO.com info@KIIROO.com +31207371194

Opening hours are: Mon - Fri, 9AM - 5PM CET.